

EYEBOLT WITH ROPEWORK IS FED THROUGH PRE-DRILLED 13mmØ POLE.

PLACE WASHER THEN NYLOC NUT OVER END AND TIGHTEN SLIGHTLY TO HOLD EYEBOLT AND ROPEWORK IN PLACE.

WHEN ALL POLES ARE SECURED IN GROUND WITH CONCRETE TIGHTEN NYLOC NUTS UNTIL EYEBOLT BEGINS TO BITE ON TIMBER AND ROPE BECOMES TAUT. FINISH BY COVERING WITH 1 Pt. CAP.

NOTE: SECTION TAKEN OUT OF POLE TO SHOW FIXING DETAIL

DRAWING TITLE:

M12 140mm EYEBOLT  
FIXING PROCEDURE

Drawn by: CS Chk'd by: R.L. (2.9.10)

© HAND MADE PLACES LTD

Kingsley House, Unit 14, Old Station Way,  
Bordon, Hants, GU35 9HH  
Tel 01420 474111 Fax 01420 474222  
e-mail: info@handmadeplaces.co.uk  
www: handmadeplaces.co.uk



For Reference Information Only - Do Not Manufacture From This Drawing