



ATTACH EYE PLATES TO THE POLES USING 6.3mmx50mm A2 HEX HEAD SECURITY SCREWS.

REMOVE SPLIT RING FROM PIN TO FIT AROUND EYE PLATE. ONCE IN PLACE REINSERT SPLIT RING THROUGH PIN TO HOLD.

TIGHTEN THE LOCKING NUTS AT EACH END OF EVERY TENSIONER HARD AGAINST THE CENTRAL BODY.

USING A SCREW DRIVER SMALL ENOUGH TO SLOT INTO THE HOLE IN THE CENTRE OF THE TENSIONER BODY, WIND UP EACH TENSIONER A FEW TURNS AT A TIME.

For Reference Information Only - Do Not Manufacture From This Drawing

DRAWING TITLE:

EYE PLATE AND M8 TENSIONER FIXING PROCEDURE

Drawn by: CS	Chk'd by:R.L (2.9.10)
--------------	-----------------------

© **HAND MADE PLACES LTD**
Kingsley House, Unit 14, Old Station Way,
Bordon, Hants. GU35 9HH
Tel 01420 474111 Fax 01420 474222
e-mail: info@handmadeplaces.co.uk
www: handmadeplaces.co.uk

