



HOLD BOARD IN PLACE TO MARK FIXING HEIGHT.

WIND SCREWS IN UNTIL IT BEGINS TO BITE ON POST/POLE. CONTINUE TO TIGHTEN UNTIL HEAD OF LANDSCAPE SCREW IS FLUSH WITH TIMBER BOARD BEING ATTACHED.



FLUSH WITH TIMBER

NOTE: DO NOT OVERTIGHTEN FIXING AS THIS WILL CAUSE TIMBER TO SPLIT



SPLITS & CRACKS AROUND SCREW HEAD

DRAWING TITLE:

LANDSCAPE SCREW
FIXING PROCEDURE

Drawn by: CS | Chk'd by: R.L (2.9.10)

© **HAND MADE PLACES LTD**

Kingsley House, Unit 14, Old Station Way,
Bordon, Hants, GU35 9HH
Tel 01420 474111 Fax 01420 474222
e-mail: info@handmadeplaces.co.uk
www: handmadeplaces.co.uk

